



Your Single Source Solution

November 27, 2017

TECHNICAL BULLETIN

Re: Line Set Insulation Sealing

In order to minimize heat loss and control condensation, proper sealing of the line set insulation is mandatory.

It is especially important to seal the end of pipe run to prevent ambient air for entering the system. Failure to do so could result in condensation formation between the insulation and pipe.

Apply the adhesive to the insulation and allow to set until tacky to the touch. Use light pressure to ensure proper adhesion to the pipe. We recommend using Armacell 520, K-Flex 620 or 720-LVOC (or equivalent) adhesives.

